


Keep Air Filters Dry




If your combat vehicle's air filters get wet or freeze up, its engine can't get the air it needs to keep running. Pretty soon you've got a burned-out engine.

So keep those air filter elements as dry as you can when Mother Nature throws a little slop your way.


Start with the air cleaner intake. When your vehicle is sitting, cover the intake with canvas or plastic to keep

out rain, sleet and snow. Make sure you remove the cover before operating, though.

During operation, keep a close eye on the air cleaner indicator or air filter clogged light so you'll know when the element is plugged. Get a plugged filter cleaned, dried out, or replaced—whichever is needed—as soon as possible.



Use tarp to cover air intake



Wet filters choke off engine air supply